





VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 3 Touring (E36) 328i 2.8, BMW 3 Saloon (E36) 328i 2.8, BMW 3 Saloon (E36) 323i 2.5, BMW 3 Coupe (E36) 328i 2.8, BMW 3 Convertible (E36) 328i 2.8, BMW 3 Convertible (E36) 323i 2.5, BMW 3 Coupe (E36) 323i 2.5, BMW 3 Touring (E36) 323i 2.5, BMW 3 Compact (E36) 323ti 2.5, BMW 3 Saloon (E46) 318i 1.9, BMW 3 Saloon (E46) 320d 2.0, BMW 3 Saloon (E46) 323i 2.5, BMW 3 Saloon (E46) 320i 2.0, BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Saloon (E46) 316i 1.9, (+ 19)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–16







REPLACEMENT: BRAKE DISCS – BMW E46 CONVERTIBLE. TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torx bit T30
- Drive socket # 16
- HEX bit No.H7.
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Tap wrench
- Impact screwdriver
- Rubber mallet
- Crow bar
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-16







Replacement: brake discs – BMW E46 convertible. AUTODOC recommends:

- Replace the brake disks on the car BMW 3 E46 in complete set for each axis.
 Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – BMW E46 CONVERTIBLE. USE THE FOLLOWING PROCEDURE:

1

Open the bonnet. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.



CLUB.AUTODOC.CO.UK 3-16







Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.



Unscrew the wheel bolts.



AUTODOC recommends:

 Important! Hold the wheel while unscrewing the fastening bolts. BMW E46 convertible

6 Remove the wheel.



CLUB.AUTODOC.CO.UK 4-16







Spread the brake pads. Use a crowbar.



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Detach the brake caliper retaining spring. Use a crowbar.



11 Remove the brake caliper.



CLUB.AUTODOC.CO.UK 5-16







Replacement: brake discs – BMW E46 convertible. Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

Remove the brake pads. Use a crowbar.

13



Disconnect the brake pads wear sensor. Use a crowbar.



Please note!

Some cars are not equipped with the brake pad wear sensor.

CLUB.AUTODOC.CO.UK 6-16







Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the caliper bracket fastening. Use a drive socket #16. Use a ratchet wrench. Use a tap wrench.



16 Remove the caliper bracket.

17



Clean the brake disk surface. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 7-16







Unscrew the brake disc fastening. Use Torx T30. Use an impact screwdriver.



Replacement: brake discs – BMW E46 convertible. AUTODOC experts recommend:

• If necessary, use a rubber mallet.

19 Remove the brake disc.

20



Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.



Move the parking brake shoes against the drum. Use a crowbar.



CLUB.AUTODOC.CO.UK 8-16







22 Install the brake disc.



Tighten the brake disc fastening. Use Torx T30. Use a torque wrench. Tighten it to 16 Nm torque.



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

 Replacement: brake discs – BMW E46 convertible. After applying the spray, wait a few minutes.

25 Install the brake caliper bracket.



CLUB.AUTODOC.CO.UK 9-16







Tighten the brake caliper bracket. Use a drive socket #16. Use a torque wrench. Tighten it to 65 Nm torque.



Treat the brake caliper piston. Use a brake cleaner.



AUTODOC recommends:

- After applying the spray, wait a few minutes.
- Press in the brake caliper piston. Use brake caliper wind back tool.



29 Install the brake pads.



CLUB.AUTODOC.CO.UK 10-16