





VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 5 Saloon (E39) 520i 2.0, BMW 5 Saloon (E39) 525tds 2.5, BMW 5 Saloon (E39) 523i 2.5, BMW 5 Saloon (E39) 528i 2.8, BMW 5 Saloon (E39) 535i 3.5, BMW 5 Touring (E39) 520i 2.0, BMW 5 Touring (E39) 523i 2.5, BMW 5 Saloon (E39) 525td 2.5, BMW 5 Touring (E39) 528i 2.8, BMW 5 Saloon (E39) 530d 3.0, BMW 5 Touring (E39) 525tds 2.5, BMW 5 Saloon (E39) 520d 2.0, BMW 5 Touring (E39) 520d 2.0, BMW 5 Saloon (E39) 525d 2.5, (+ 5)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-18







REPLACEMENT: BRAKE DISCS – BMW E39. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- HEX bit no.H6.
- HEX bit no.H7.
- Drive socket # 18
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Impact screwdriver
- Crow bar
- Fender cover
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-18







Replacement: brake discs – BMW E39. AUTODOC experts recommend:

- Replace the brake disks on the car BMW E39 in complete set for each axis.
 Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – BMW E39. TAKE THE FOLLOWING STEPS:

1

Open the hood.



- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Detach the air duct from the cabin filter housing.



CLUB.AUTODOC.CO.UK 3-18







Release the cabin filter cover clips.



Remove the cabin filter housing cover.



6 Remove the cabin filter housing seal.



Remove the cabin air filter housing.



Unscrew the brake fluid reservoir cap.



CLUB.AUTODOC.CO.UK 4-18







9 Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.



12 Unscrew the wheel bolts.



Replacement: brake discs – BMW E39. Tip from AUTODOC:

• To avoid injury, hold up the wheel when unscrewing the bolts.

CLUB.AUTODOC.CO.UK 5-18








Remove the wheel.



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.



Detach the brake caliper retaining spring. Use a crowbar.



CLUB.AUTODOC.CO.UK 6-18







18 Remove the brake caliper.



Replacement: brake discs – BMW E39. AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

19 Remove the brake pads.



CLUB.AUTODOC.CO.UK 7–18







Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench.



Remove the caliper bracket.

23



Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 8-18







Unscrew the brake disc fastening. Use HEX No.H6. Use an impact screwdriver.



Remove the brake disc.



Clean the hub. Use a wire brush.



Treat the contacting surface. Use copper grease.



28 Install the brake disc.



CLUB.AUTODOC.CO.UK 9-18







Tighten the brake disc fastening. Use HEX No.H6. Use a torque wrench. Tighten it to 16 Nm torque.



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

 Replacement: brake discs – BMW E39. After applying the spray, wait a few minutes.

31

30

Install the brake caliper bracket.



CLUB.AUTODOC.CO.UK 10-18