






### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### i Important!

This replacement procedure can be used for: BMW 6 Convertible (E64) 645Ci 4.4, BMW 6 Convertible (E64) 630i 3.0, BMW 6 Convertible (E64) 650i 4.8, BMW 6 Convertible (E64) 635d 3.0, BMW 6 Convertible (E64) 630i 3.0 (N52B30A, N52B30 B, N52B30BF)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E60) 525d 2.5

CLUB.AUTODOC.CO.UK 1–22







# REPLACEMENT: WHEEL BEARING – BMW 6 CONVERTIBLE (E64). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- All-purpose cleaning spray
- Brake cleaner
- Copper grease
- Combination spanner #9
- Combination spanner #18
- Drive socket # 10
- Drive socket # 16
- Drive socket # 18
- Drive socket # 21

- HEX bit no.H6.
- Shock absorber socket
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Tap wrench
- Impact screwdriver
- Crow bar
- Hydraulic transmission jack
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-22







### Replacement: wheel bearing – BMW 6 Convertible (E64). Tip from AUTODOC:

- Do not re-use the bearing assembly of your BMW 6 Convertible (E64) car.
- The wheel hub bearing replacement procedure is identical for both wheels on the same axle.
- All work should be done with the engine stopped.

# REPLACEMENT: WHEEL BEARING – BMW 6 CONVERTIBLE (E64). RECOMMENDED SEQUENCE OF STEPS:

1 Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-22







4 Unscrew the wheel bolts.



## Replacement: wheel bearing – BMW 6 Convertible (E64). Tip from AUTODOC:

• To avoid injury, hold up the wheel when unscrewing the bolts.

Remove the wheel.



6 Spread the brake pads. Use a crowbar.



Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench.



CLUB.AUTODOC.CO.UK 4-22







B Disconnect the brake hose. Use a crowbar.



Remove the brake caliper together with its bracket.



### **AUTODOC** recommends:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



10

CLUB.AUTODOC.CO.UK 5-22







Unscrew the brake disc fastening. Use HEX No.H6. Use an impact screwdriver.



Remove the brake disc.



Clean the wheel hub fastener. Use a wire brush. Use WD-40 spray.



14 Disconnect the ABS sensor wiring.



CLUB.AUTODOC.CO.UK 6-22







Clean the fasteners connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.



- Prop up the steering knuckle. Use a hydraulic transmission jack.
- Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a drive socket #18. Use a ratchet wrench.



Unscrew the fastener of the stabiliser link bracket. Use a drive socket #16. Use a ratchet wrench.



19 Remove the fastening bolt.



CLUB.AUTODOC.CO.UK 7-22







Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



Unscrew the fasteners of the headlight levelling sensor. Use a drive socket #10. Use a ratchet wrench.



Disconnect the headlight levelling sensor.

23



Unscrew the rear fastener connecting the control arm to the subframe. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 8-22







Unscrew the front arm fastener. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



Release the lower fastener connecting the shock strut to the steering knuckle. Use a special drive socket to remove the shock absorber. Use a ratchet wrench.



Lower the hydraulic transmission jack by 10-15 cm.



#### **AUTODOC** recommends:

• Replacement: wheel bearing – BMW 6 Convertible (E64). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

CLUB.AUTODOC.CO.UK 9-22







Disconnect the steering knuckle from the shock absorber strut.



Clean the wheel hub fastener. Use a wire brush. Use WD-40 spray.



Unscrew the end fastening nut to the steering knuckle. Use a drive socket #21. Use a ratchet wrench.



Disconnect the tie rod end from the steering knuckle.



Remove the rear fastener of the control arm.

31



CLUB.AUTODOC.CO.UK 10-22