





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: BMW 7 (E23) 728 2.8, BMW 7 (E23) 728i 2.8, BMW 7 (E23) 730 3.0, BMW 7 (E23) 733i 3.2, BMW 7 (E23) 745i 3.2, BMW 7 (E23) 735i 3.5, BMW 7 (E23) 745i 3.5, BMW 7 (E23) 732i 3.2

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW X5 (E53) 4.4 i

CLUB.AUTODOC.CO.UK 1-6







Replacement: windshield wipers – BMW 7 (E23). Tip from AUTODOC experts:

- Always replace front wiper blades together. It will ensure efficient and uniform cleaning of the windshield.
- Don't confuse the wiper blades of the driver and passenger side.
- The replacement procedure for both wiper blades is identical.
- Please note: all work on the car BMW 7 (E23) should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- 1 Prepare the new windscreen wipers.
 - Pull the wiper arm away from the glass surface until it stops.



Press the clip. Remove the blade from the wiper arm.



CLUB.AUTODOC.CO.UK 2-5







Replacement: windshield wipers – BMW 7 (E23). AUTODOC recommends:

 When replacing the wiper blade, take caution to prevent the spring-loaded wiper arm from hitting the glass.

4

Install the new wiper blade and carefully press the wiper arm down to the glass.



Replacement: windshield wipers – BMW 7 (E23). Professionals recommend:

- Don't touch the wiper blade at the working rubber edge to prevent damage to the graphite coating.
- Ensure that the blade rubber strip fits tightly to the glass along the entire length.

5

Switch on the ignition.

CLUB.AUTODOC.CO.UK 3-5







6

After installation check the wipers performance. The blades shouldn't intersect or bump against the windshield seal.







VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 4-5