






#### **VIDEO TUTORIAL**



## (i) Important!

This replacement procedure can be used for:

BMW 5 Saloon (E39) 520i 2.0, BMW 5 Saloon (E39) 525tds 2.5, BMW 5 Saloon (E39) 523i 2.5, BMW 5 Saloon (E39) 528i 2.8, BMW 5 Saloon (E39) 540i 4.4, BMW 5 Saloon (E39) 535i 3.5, BMW 5 Touring (E39) 520i 2.0, BMW 5 Touring (E39) 523i 2.5, BMW 5 Touring (E39) 540i 4.4, BMW 5 Saloon (E39) 525td 2.5, BMW 5 Touring (E39) 528i 2.8, BMW 5 Saloon (E39) 530d 3.0, BMW 5 Touring (E39) 530d 3.0, BMW 5 Touring (E39) 525tds 2.5, BMW 5 Saloon (E39) 520d 2.0, (+ 26)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-14







# REPLACEMENT: REAR UPPER ARM – BMW E60. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Combination spanner #21
- Drive socket # 18
- Drive socket # 21

- Torx bit T40
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Tap wrench
- Crow bar
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-14








#### Replacement: rear upper arm – BMW E60. AUTODOC experts recommend:

- The replacement procedure is identical for the right and left upper control arms.
- Please note: all work on the car BMW E60 should be done with the engine switched off.

### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.



CLUB.AUTODOC.CO.UK 3-14







4 Unscrew the wheel bolts.



#### AUTODOC recommends:

• Important! Hold the wheel while unscrewing the fastening bolts. BMW E60

Remove the wheel.



6 Disconnect the brake pads wear sensor.



#### Please note!

• Some cars are not equipped with the brake pad wear sensor.

CLUB.AUTODOC.CO.UK 4–14







Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench.



Remove the brake caliper together with its bracket.



#### **AUTODOC** recommends:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

CLUB.AUTODOC.CO.UK 5-14







Clean the fasteners connecting the control arm to the subframe. Use a wire brush. Use WD-40 spray.



Unscrew the arm fastening from the subframe. Use a combination spanner #18 (2 pieces).



Disconnect the ABS sensor wiring. Use a crowbar.

13



Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 6-14







Unscrew the fastener connecting the control arm to the rear knuckle. Use a combination spanner #21. Use Torx T40. Use a ratchet wrench.



15 Remove the fastening bolt.



16 Remove the rear upper arm.

17



Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 7-14







Mount the rear upper arm.



# Replacement: rear upper arm – BMW E60. AUTODOC recommends:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.

19 Install the fastening bolt.

20



Screw in the fastener that connects the control arm to the rear knuckle. Use a drive socket #21. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 8-14







Support the stub axle. Use a hydraulic transmission jack.



Tighten the fastener connecting the suspension arm to the rear knuckle. Use a drive socket #21. Use a torque wrench. Tighten it to 165 Nm torque.



Tighten the arm fastening to the subframe. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 100 Nm torque.



Remove the support from under the stub axle.

24



#### **AUTODOC** recommends:

 Replacement: rear upper arm – BMW E60. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

CLUB.AUTODOC.CO.UK 9-14







Connect the ABS sensor wiring.



Install the brake caliper together with its bracket.



Tighten the brake caliper bracket. Use a drive socket #18. Use a torque wrench. Tighten it to 110 Nm torque.



Connect the brake pads wear sensor.

29



Treat all joints of the arm. Use copper grease.



CLUB.AUTODOC.CO.UK 10-14