# **+** AUTODOC CLUB


How to change front lower arm on **BMW X3 E83** – replacement guide







#### **VIDEO TUTORIAL**



### i Important!

This replacement procedure can be used for:

BMW X3 (E83) xDrive 20 d, BMW X3 (E83) xDrive 30 d, BMW X3 (E83) 3.0 i xDrive, BMW X3 (E83) 3.0 d, BMW X3 (E83) 2.0 d, BMW X3 (E83) 2.0 i, BMW X3 (E83) 3.0 si, BMW X3 (E83) 2.5 si, BMW X3 (E83) 3.0 sd, BMW X3 (E83) xDrive 20 i, BMW X3 (E83) xDrive 25 i, BMW X3 (E83) xDrive 30 i, BMW X3 (E83) xDrive 18 d, BMW X3 (E83) xDrive 35 d, BMW X3 (E83) 2.5 si xDrive

The steps may slightly vary depending on the car design.


CLUB.AUTODOC.CO.UK 1–12







## REPLACEMENT: FRONT LOWER ARM – BMW X3 E83. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #16
- Combination spanner #22

- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench
- Ball joint puller
- Hydraulic transmission jack
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-12







#### Replacement: front lower arm – BMW X3 E83. AUTODOC experts recommend:

- The replacement procedure is identical for the left and right lower control arms.
- All work should be done with the engine stopped.

## REPLACEMENT: FRONT LOWER ARM – BMW X3 E83. USE THE FOLLOWING PROCEDURE:

- Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.



Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 3-12







#### **AUTODOC** recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 BMW X3 E83

Remove the wheel.



Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



#### **AUTODOC** recommends:

- Replacement: front lower arm BMW X3 E83. After applying the spray, wait a few minutes.
- Unscrew the fastener connecting the control arm to the subframe. Use a combination spanner #16. Use a drive socket #18. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4-12








Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #22.



Disconnect the ball joint from the steering knuckle. Use a ball joint puller.



10 Remove the fastening bolt.



11 Remove the arm.

12



Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 5-12







13 Install a new arm.



## Replacement: front lower arm – BMW X3 E83. Professionals recommend:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.
- 14 Install the fastening bolt.



Connect the ball joint to the steering knuckle.



CLUB.AUTODOC.CO.UK 6-12







Screw the fastener connecting the ball joint to the steering knuckle. Use a combination spanner #22.



Screw the fastener connecting the control arm to the subframe. Use a combination spanner #16. Use a drive socket #18. Use a ratchet wrench.



Support the arm. Use a hydraulic transmission jack.



Tighten the fasteners connecting the control arm and the subframe. Use a combination spanner #16. Use a drive socket #18. Use a torque wrench. Tighten it to 110 Nm torque.



CLUB.AUTODOC.CO.UK 7-12







Tighten the fastener connecting the ball joint to the steering knuckle. Use a combination spanner #22. Use a torque wrench. Tighten it to 60 Nm torque.



Remove the support from under the arm.



#### **AUTODOC** recommends:

- BMW X3 E83 Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.
- Treat all joints of the arm. Use copper grease.



Clean the wheel rim mounting seat. Use a wire brush.



CLUB.AUTODOC.CO.UK 8-12







Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



#### **AUTODOC** recommends:

 Replacement: front lower arm – BMW X3 E83. After applying the spray, wait a few minutes.

26 Install the wheel.



#### **AUTODOC** recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW X3 E83

CLUB.AUTODOC.CO.UK 9-12







Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 140 Nm torque.



Remove the jacks and chocks.





**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 10-12





# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**BUY SPARE PARTS FOR BMW** 

**CONTROL ARM: A WIDE SELECTION** 

CLUB.AUTODOC.CO.UK 11-12







**CONTROL ARM FOR BMW: BUY NOW** 

CONTROL ARM FOR BMW X3 E83: THE BEST DEALS & OFFERS

### **① DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 12-12