





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 5 Touring (E39) 520i 2.0, BMW 5 Touring (E39) 523i 2.5, BMW 5 Touring (E39) 528i 2.8, BMW 5 Touring (E39) 530d 3.0, BMW 5 Touring (E39) 525tds 2.5, BMW 5 Touring (E39) 520d 2.0, BMW 5 Touring (E39) 525d 2.5, BMW 5 Touring (E39) 520i 2.2, BMW 5 Touring (E39) 525i 2.5

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E39) 520i 2.0

CLUB.AUTODOC.CO.UK 1–16







REPLACEMENT: BRAKE DISCS – BMW 5 TOURING (E39). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- HEX bit no.H6.
- HEX bit no.H7.
- Drive socket # 18
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Impact screwdriver
- Crow bar
- Fender cover
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-16








Replacement: brake discs – BMW 5 Touring (E39). AUTODOC experts recommend:

- Replace the brake disks on the car BMW 5 Touring (E39) in complete set for each axis. Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – BMW 5 TOURING (E39). TAKE THE FOLLOWING STEPS:

- Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Detach the air duct from the cabin filter housing.



Release the cabin filter cover clips.



CLUB.AUTODOC.CO.UK 3-16







Remove the cabin filter housing cover.



Remove the cabin filter housing seal.



Remove the cabin air filter housing.



8 Unscrew the brake fluid reservoir cap.



9 Secure the wheels with chocks.



CLUB.AUTODOC.CO.UK 4-16







Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the front of the car and secure on supports.
- 12 Unscrew the wheel bolts.



Replacement: brake discs – BMW 5 Touring (E39). Tip from AUTODOC:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.



CLUB.AUTODOC.CO.UK 5-16








Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.



Detach the brake caliper retaining spring. Use a crowbar.



18 Remove the brake caliper.



CLUB.AUTODOC.CO.UK 6-16







Replacement: brake discs – BMW 5 Touring (E39). AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them.
 Replace, if necessary.

19 Remove the brake pads.

20



Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 7–16







Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench.



Remove the caliper bracket.

24



Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the brake disc fastening. Use HEX No.H6. Use an impact screwdriver.



CLUB.AUTODOC.CO.UK 8-16







Remove the brake disc.



Clean the hub. Use a wire brush.



Treat the contacting surface. Use copper grease.



28 Install the brake disc.

29



Tighten the brake disc fastening. Use HEX No.H6. Use a torque wrench. Tighten it to 16 Nm torque.



CLUB.AUTODOC.CO.UK 9-16







Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

• Replacement: brake discs – BMW 5 Touring (E39). After applying the spray, wait a few minutes.

Install the brake caliper bracket.

32



Tighten the brake caliper bracket. Use a drive socket #18. Use a torque wrench. Tighten it to 110 Nm torque.



CLUB.AUTODOC.CO.UK 10-16