

VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:
BMW X3 (E83) xDrive 20 d, BMW X3 (E83) xDrive 30 d, BMW X3 (E83) 3.0 d, BMW X3 (E83) xDrive 18 d, BMW X3 (E83) xDrive 35 d

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–9



REPLACEMENT: AIR FILTER – BMW X3 E83. TOOLS YOU MIGHT NEED:



- Flat Screwdriver
- Microfibre towel

Fender cover

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-9





Replacement: air filter – BMW X3 E83. Professionals recommend:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- All work should be done with the engine stopped.

REPLACEMENT: AIR FILTER – BMW X3 E83. RECOMMENDED SEQUENCE OF STEPS:

Open the bonnet.



- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Detach the windscreen washer hose. Use a flat screwdriver.



Unplug the mass air flow sensor connector. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 3–9







Unscrew the clamp that fastens the air filter hose to the throttle body. Use a flat screwdriver.



Release the air filter cover clips. Use a flat screwdriver.



Take off the filter lid. Use a flat screwdriver.



Remove the filter element from the filter housing.



Clean the air filter cover and housing.

CLUB.AUTODOC.CO.UK 4–9





Replacement: air filter – BMW X3 E83. AUTODOC recommends:

 Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.



Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



AUTODOC recommends:

- Replacement: air filter BMW X3 E83. Be sure to position the filtering element correctly. Avoid misalignment.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.
- Take care to only use quality filters.



Reinstall the air filter cover. Fasten it. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 5–9





Press the air filter cover clips into place.



Screw in the clamp that connects the air filter hose to the throttle body. Use a flat screwdriver.



Plug in the mass air flow sensor conntector.



15 Attach the windscreen washer hose.



16 Remove the fender protection cover.

CLUB.AUTODOC.CO.UK 6-9







17


Close the hood.






VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 7-9





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR BMW

AIR FILTER: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 8-9