





VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 325i 3.0, BMW 3 Touring (E91) 318d 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW X1 (E84) xDrive 28 i, BMW 3 Touring (E91) 318i 2.0, BMW 3 Touring (E91) 316d 2.0, BMW 3 Saloon (E90) 320d xDrive 2.0, BMW X1 (E84) sDrive 20 i, BMW X1 (E84) xDrive 20 i, BMW 1 Coupe (E82) 118d 2.0, BMW 3 Saloon (F30, F80) 328i 2.0, BMW 3 Coupe (E92) 318i 2.0, BMW 3 Convertible (E93) 318i 2.0, BMW 1 Hatchback (E81) 116i 1.6, BMW 1 Hatchback (E81) 120d 2.0, (+75)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–15







REPLACEMENT: BRAKE PADS – BMW E82. TOOLS YOU MIGHT NEED:



- Wire brush
- Brake cleaner
- Anti-squeal paste
- Copper grease
- HEX bit no.H7.
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Crow bar
- Fender cover
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-15







Replacement: brake pads – BMW E82. Tip from AUTODOC experts:

- Perform the replacement of brake pads in complete set for each axis. This
 provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE PADS – BMW E82. TAKE THE FOLLOWING STEPS:

Open the bonnet.



- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Remove the wiper arm cover.



CLUB.AUTODOC.CO.UK 3-15







4 Unscrew the brake fluid reservoir cap.



5 Secure the wheels with chocks.



6 Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the rear of the car and secure on supports.



CLUB.AUTODOC.CO.UK 4-15







8 Unscrew the wheel bolts.



AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 BMW E82

Remove the wheel.

10



Disconnect the brake pads wear sensor. Use a crowbar.



Please note!

• Some cars are not equipped with the brake pad wear sensor.

CLUB.AUTODOC.CO.UK 5-15







Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.

14



Detach the brake caliper retaining spring. Use a crowbar.



CLUB.AUTODOC.CO.UK 6-15







15 Remove the brake caliper.



Replacement: brake pads – BMW E82. AUTODOC recommends:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

16 Remove the brake pads.



CLUB.AUTODOC.CO.UK 7–15







Replacement: brake pads – BMW E82. Tip:

 Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

17

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



Replacement: brake pads – BMW E82. Tip from AUTODOC:

• After applying the spray, wait a few minutes.

18

Treat the brake caliper piston. Use a brake cleaner.



AUTODOC recommends:

 Replacement: brake pads – BMW E82. After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 8-15







Press in the brake caliper piston. Use brake caliper wind back tool.



Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



Replacement: brake pads – BMW E82. Professionals recommend:

• Make sure the disc surface is clean before installing the pads.

Install new brake pads.



CLUB.AUTODOC.CO.UK 9-15







Replacement: brake pads – BMW E82. AUTODOC experts recommend:

• Make sure the pads are installed with linings facing the disc.





23 Install the dust boot caps of the brake caliper guide pins.



Connect the brake pads wear sensor.



Install the brake caliper retaining spring.

25



CLUB.AUTODOC.CO.UK 10-15