





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 5 Touring (E39) 520i 2.0, BMW 5 Touring (E39) 523i 2.5, BMW 5 Touring (E39) 540i 4.4, BMW 5 Touring (E39) 528i 2.8, BMW 5 Touring (E39) 530d 3.0, BMW 5 Touring (E39) 525tds 2.5, BMW 5 Touring (E39) 520d 2.0, BMW 5 Touring (E39) 525d 2.5, BMW 5 Touring (E39) 520i 2.2, BMW 5 Touring (E39) 525i 2.5, BMW 5 Touring (E39) 530i 3.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E60) 520d 2.0


CLUB.AUTODOC.CO.UK 1–20







REPLACEMENT: WHEEL BEARING – BMW 5 TOURING (E39). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #10
- Combination spanner #18
- Drive socket # 10
- Drive socket # 18
- Drive socket # 19
- Drive socket # 21
- Drive socket # 24
- Drive socket # 36
- Drive socket # E12
- Drive socket # E14
- HEX bit no.H6.

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Crow bar
- Rubber mallet
- Hub slide hammer puller
- Flat chisel
- Hammer
- Pin punch
- Bush and bearing driver set
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-20







Replacement: wheel bearing – BMW 5 Touring (E39). Professionals recommend:

- Do not re-use the bearing assembly of your BMW 5 Touring (E39) car.
- The wheel hub bearing replacement procedure is identical for both wheels on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: WHEEL BEARING – BMW 5 TOURING (E39). TAKE THE FOLLOWING STEPS:

1 Secure the

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-20







4 Unscrew the wheel bolts.



Replacement: wheel bearing – BMW 5 Touring (E39). Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.

Remove the wheel.



6 Unstake the wheel hub retaining nut. Use a flat metal-working chisel. Use a hammer.



Unscrew the wheel hub axle nut. Use a drive socket #36. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4-20







Remove the fastening nut.

11

Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the caliper bracket fastening. Use a drive socket #18. Use a ratchet wrench.



Remove the brake caliper together with its bracket. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 5-20







Replacement: wheel bearing – BMW 5 Touring (E39). AUTODOC recommends:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



13

Unscrew the brake disc fastening. Use HEX No.H6. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 6-20







Remove the brake disc. Use a rubber mallet.



Using a puller, remove the wheel hub from the bearing. Use the hub slide hammer puller.



Pull the bearing inner race out of the wheel hub. Use a rubber mallet.



- Clean all joints of the arm. Use a wire brush. Use WD-40 spray.
- Unscrew the front fastener connecting the rear knuckle to the suspension control arm. Use a combination spanner #18. Use a drive socket #24. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 7-20







Unscrew the rear fastener connecting the control arm to the subframe. Use a combination spanner #18. Use a drive socket #21. Use a ratchet wrench.



Unscrew the fastener connecting the stabilizer bar with the control arm. Use a drive socket #19. Use a ratchet wrench.



Unscrew the rear fastener connecting the control arm to the subframe. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



22

Remove the rear fastener of the control arm. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 8-20







Clean the fasteners of the headlight levelling sensor. Use a wire brush. Use WD-40 spray.



Unscrew the fasteners of the headlight levelling sensor. Use a combination spanner #10. Use a drive socket #10. Use a ratchet wrench.



Disconnect the headlight levelling sensor.



Remove the rear fastener of the control arm. Use a pin punch. Use a hammer.



Remove the stabilizer rod.

26

CLUB.AUTODOC.CO.UK 9-20







Detach the control arm. Use a crowbar.



Unscrew the fastening bolts of the drive shaft from the reduction gear. Use a drive socket #E12. Use a ratchet wrench.



Remove the drive shaft. Use a rubber mallet.

31



Unscrew the fastening bolts of the rear wheel hub bearing. Use a drive socket #E14. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 10-20