

VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 7 (E65, E66, E67) 730d 3.0, BMW 7 (E65, E66, E67) 735i / Li 3.6, BMW 7 (E65, E66, E67) 745i / Li 4.4, BMW 7 (E65, E66, E67) 740d 3.9, BMW 7 (E65, E66, E67) 760i / Li 6.0, BMW 5 Saloon (E60) 520i 2.2, BMW 5 Saloon (E60) 530i 3.0, BMW 5 Saloon (E60) 530d 3.0, BMW 5 Saloon (E60) 525i 2.5, BMW 5 Saloon (E60) 545i 4.4, BMW 5 Touring (E61) 525i 2.5, BMW 5 Touring (E61) 545i 4.4, BMW 5 Touring (E61) 530d 3.0, BMW 6 Coupe (E63) 645Ci 4.4, BMW 6 Convertible (E64) 645Ci 4.4, (+ 52)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–12



REPLACEMENT: REAR LOWER ARM – BMW E60. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Combination spanner #21
- Drive socket # 10

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Crow bar
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-12





Replacement: rear lower arm – BMW E60. Tip from AUTODOC experts:

- The replacement procedure is identical for the right and left upper control arms.
- Please note: all work on the car BMW E60 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the rear of the car and secure on supports.
- Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 3-12







Replacement: rear lower arm – BMW E60. Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.



8



Disconnect the ABS sensor wiring. Use a flat screwdriver.



Disconnect the brake pad wear sensor cable. Use a flat screwdriver.



Remove the mounting bracket of the ABS sensor wiring from the upper arm. Use a flat screwdriver.




CLUB.AUTODOC.CO.UK 4-12







- Clean all joints of the arm. Use a wire brush. Use WD-40 spray.
- Unscrew the front arm fastener. Use a combination spanner #18 (2 pieces).



Remove the front fastener of the control arm. Use a crowbar. Use a flat screwdriver.



Unscrew the fastener connecting the control arm to the rear knuckle. Use a combination spanner #21. Use a drive socket #10. Use a ratchet wrench.



Detach the suspension arm from the rear knuckle.



CLUB.AUTODOC.CO.UK 5-12





14 Remove the arm.



- Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.
- 16 Install a new arm.



Replacement: rear lower arm – BMW E60. AUTODOC recommends:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.
- Attach the suspension arm to the rear knuckle.
- Tighten the fastener connecting the suspension arm to the rear knuckle. Use a combination spanner #21. Use a drive socket #10. Use a torque wrench. Tighten it to 165 Nm torque.



CLUB.AUTODOC.CO.UK 6-12







19 Install the front fastener of the arm.




Screw the front arm fastener. Use a combination spanner #18 (2 pieces).



Support the stub axle. Use a hydraulic transmission jack.



Tighten the front fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces). Use a torque wrench. Tighten it to 100 Nm torque.



CLUB.AUTODOC.CO.UK 7-12







Remove the support from under the stub axle.



AUTODOC recommends:

- Replacement: rear lower arm BMW E60. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.
- Install the mounting bracket of the ABS sensor wiring onto the upper arm.



- Connect the brake pad wear sensor cable.
- Connect the ABS sensor wiring.



CLUB.AUTODOC.CO.UK 8-12







Treat all joints of the arm. Use copper grease.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



Replacement: rear lower arm – BMW E60. AUTODOC experts recommend:

• After applying the spray, wait a few minutes.

30 Install the wheel.



CLUB.AUTODOC.CO.UK 9-12







AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW E60






Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



Remove the jacks and chocks.





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 10-12