






### **VIDEO TUTORIAL**



# (i) Important!

This replacement procedure can be used for:

BMW 3 Saloon (E36) 316i 1.6, BMW 3 Saloon (E36) 318i 1.8, BMW 3 Saloon (E36) 318is 1.8, BMW 3 Coupe (E36) 318is 1.8, BMW 3 Saloon (E36) 320i 2.0, BMW 3 Coupe (E36) 320i 2.0, BMW 3 Saloon (E36) 325i 2.5, BMW 3 Coupe (E36) 325i 2.5, BMW 3 Coupe (E36) 325i 2.5, BMW 3 Convertible (E36) 320i 2.0, BMW 3 Convertible (E36) 325i 2.5, BMW 3 Coupe (E36) 316i 1.6, BMW 3 Convertible (E36) 318i 1.8, BMW 3 Saloon (E36) 318tds 1.7, (+ 19)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–16







# REPLACEMENT: BRAKE DISCS – BMW E36. TOOLS YOU MIGHT NEED:



- Wire brush
- Nylon cleaning brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Drive socket # 16
- HEX bit No.H6
- HEX bit No.H7

- Wheel impact socket #17
- Ratchet wrench
- Round-nose pliers
- Tap wrench
- Flat screwdriver
- Impact screwdriver
- Brake caliper wind back tool
- Crow bar
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-16







#### **AUTODOC** recommends:

- Replace the brake disks on the car BMW E36 in complete set for each axis.
  Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- Please note: all work on the car BMW E36 should be done with the engine switched off.

# CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the hood. Unscrew the brake fluid reservoir cap.



- 2 Secure the wheels with chocks.
- Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 3-16







A Raise the rear of the car and secure on supports.



5 Unscrew the wheel bolts.



#### **AUTODOC** recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
  BMW E36
- Remove the wheel.



Remove the brake pad wear sensor from the brake pad. Use round-nose pliers.



CLUB.AUTODOC.CO.UK 4–16







Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Detach the brake caliper retaining spring. Use a crowbar. Use a flat screwdriver.



Spread the brake pads. Use a crowbar.

11



CLUB.AUTODOC.CO.UK 5-16







12 Remove the brake caliper.



# Replacement: brake discs – BMW E36. Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

Remove the brake pads.

13



CLUB.AUTODOC.CO.UK 6-16







Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the caliper bracket fastening. Use a drive socket #16. Use a tap wrench.



16 Remove the caliper bracket.

17



Clean the brake disc fastener. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 7-16







Unscrew the brake disc fastening. Use HEX No.H6. Use an impact screwdriver.



19 Remove the brake disc.



Clean the hub. Use a wire brush. Use a brake cleaner.



# **AUTODOC** recommends:

- Replacement: brake discs BMW E36. After applying the spray, wait a few minutes.
- Treat the contacting surface. Use copper grease.



CLUB.AUTODOC.CO.UK 8-16







22 Install the brake disc.



Tighten the brake disc fastening. Use HEX No.H6. Use a torque wrench. Tighten it to 9 Nm torque.



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



# Replacement: brake discs – BMW E36. AUTODOC recommends:

• After applying the spray, wait a few minutes.

Install the brake caliper bracket.

25



CLUB.AUTODOC.CO.UK 9-16







Tighten the brake caliper bracket. Use a drive socket #16. Use a torque wrench. Tighten it to 65 Nm torque.



Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.



#### **AUTODOC** recommends:

 Replacement: brake discs – BMW E36. After applying the spray, wait a few minutes.

Press in the brake caliper piston. Use brake caliper wind back tool.



CLUB.AUTODOC.CO.UK 10-16